



Individual locking 'Indivast'

With the Indivast you can individual secure the cows in the feed front.

It makes inseminating or other treatments much easier. The Indivast has two gaps in the steel profile which can be clamped on the bar and the frame.

Locking is easy, place the Indivast rectangular opposite the under tube after which a quarter turn is made. Push it with a little strength below the feed front. The Indivast then lies horizontal on the under tube.



item no.

Indivast for self locking feed front 22.61 / 22.62 —	22.92.650
Indivast for safety feed front 22.72 / 23.71 —	22.92.750

